

6 - Table of parameters and messages

Def. column shows factory-set default parameters. Those marked with * are variable parameters depending on the application chosen in the wizard or the P3 parameter (see table "Default parameters by application"). If not indicated otherwise, the temperature values are in °C. (Equivalent values in °F).

Level 1 Menus and description						
rE	Level 2 Control	Level 3 Description	Values	Min.	Def.	Max.
SP	Temperature Adjustment (Set Point) (limits depending on probe type)	With NTC (°C/F) With PTC	-50 (-58°F) - 150 (302°F)	*	99 (210°F)	● ●
	Calibrating probe 1 (Offset)	°C/F	-20,0	0,0	20,0	● ●
C1	Probe 1 differential (Hysteresis)	°C/F	0,1	2,0	20,0	● ●
C2	Upper blocking of the set point (cannot be set above this value)	With NTC (°C/F) With PTC	C3	99 (210°F) - 150 (302°F)	99 (210°F)	● ●
	Lower blocking of the set point (cannot be set below this value)	°C/F	-50 (-58°F)	-50 (-58°F)	C2	● ●
C4	Type of delay for protection of the compressor: 0=OFF/ON (since the last disconnection); 1=OFF-ON/ON-OFF (since the last shut-down /start-up)		0	0	1	● ●
C5	Protection delay time (value of the option selected in parameter C4)	(min.)	0	0	120	● ●
C6	Status of COOL relay with probe fault 0=OFF; 1=ON; 2=Average based on last 24 hours prior to probe fault; 3=ON-OFF as prog. C7 and C8		0	2	3	● ●
C7	Time relay ON in case of faulty probe (If C7=0 and C8=0, the relay will always be OFF deenergised)	(min.)	0	10	120	● ●
C8	Time relay OFF in case of fault of probe 1 (If C8=0 and C7=0, the relay will always be ON energised)	(min.)	0	5	120	● ●
C9	Maximum duration of fast freezing mode. (0=off)	(h.)	0	24	48	● ●
C10	Change set point (SP) in fast freezing mode, when it reaches this point (SP+C10) returns to normal. (SP+C10 ≥ C3) (0=OFF)	°C/F	0	-50 (-58°F)	C3-SP	● ●
C11	Length of inactivity at digital input to activate ECO mode (Only if P10 or P11=1 and P0=0) (0=OFF)	(h.)	0	2	24	● ●
C12	Change set point (SP) in ECO mode (SP+C12 ≤ C2) (0=off)	°C/F	0	2	C2-SP	● ●
EP	Exit to Level 1					● ●
Level 2 DEFROST Control (if P0=0 Direct, Cold)						
dEF	Level 3 Description	Values	Min.	Def.	Max.	
d0	Defrost frequency (Time between two starts)	(h.)	0	*	96	● ●
d1	Maximum defrost duration (0=defrost deactivated)	(min.)	0	*	255	● ●
d2	Type of message during defrost: 0=Current temperature; 1=Temperature at start of defrost; 2=Display dEF message		0	2	2	● ●
d3	Maximum duration of message (time added at the end of the defrost)	(min.)	0	5	255	● ●
d4	Defrost end temperature (probe 2) (If P4 ≠ 1)	°C/F	-50 (-58°F)	8 (46°F)	99,9 (211°F)	● ●
d5	Defrost on equipment start-up 0=NO, First defrost as per d0, 1=YES, First defrost as per d6		0	0	1	● ●
d6	Defrost start delay on equipment start-up	(min.)	0	0	255	● ●
d7	Defrost type: 0=Resistors, 1=Inverted cycle, 2=Fan/air (In two-relay equipment, P6 must be programmed to zero), 3=Compressor off		0	0	3	● ●
d8	Calculated time between defrost periods: 0=Total actual time; 1=Sum of times the compressor is on		0	0	1	● ●
d9	Drip time at end of defrost (compressor and fans off) (If P4 ≠ 1)	(min.)	0	1	255	● ●
EP	Exit to Level 1					● ●
Level 2 FAN control (Evaporator)						
In 2-relay models P6 must be set to 0						
Fan	Level 3 Description	Values	Min.	Def.	Max.	
F0	Fan shut-down temperature as per probe 2 (if P4 ≠ 1)	°C/F	-50 (-58°F)	*	99,9 (211°F)	● ●
F1	Probe 2 differential (If P4 ≠ 1)	°C/F	0,1	2,0	20,0	● ●
F2	Stop fans when stopping compressor 0=No, 1=Yes		0	1	1	● ●
F3	Fan status during defrost: 0=Off; 1=On		0	*	1	● ●
F4	Starting delay after defrost (if F3=0) Will only operate if it is higher than d9	(min.)	0	3	99	● ●
F5	Stop fans on opening the door 0=No, 1=Yes (Requires a digital input configured as port P10 or P11=1)		0	0	1	● ●
EP	Exit to Level 1					● ●
Level 2 ALARMS control (visual)						
AL	Level 3 Description	Values	Min.	Def.	Max.	
A0	Configuration of temperature alarms: 0=Relative to SP; 1=Absolute		0	0	1	● ●
A1	Maximum alarm probe 1 (must be greater than SP)	With NTC (°C/F) With PTC	A2	99,9 (211°F) - 150 (302°F)	99,9 (211°F)	● ●
	Minimum alarm probe 1 (must be less than SP)	°C/F	-50 (-58°F)	-50 (-58°F)	A1	● ●
A3	Temperature alarm delay during start-up	(min.)	0	0	120	● ●
A4	Temperature alarm delay after completion of a defrost	(min.)	0	0	99	● ●
A5	Temperature alarm delay after reaching the value of A1 or A2	(min.)	0	30	99	● ●
A6	External alarm delay when receiving digital input signal (P10 or P11=2 or 3)	(min.)	0	0	120	● ●
A7	Deactivation delay of the external alarm when the signal of the digital input disappears (P10 or P11=2 or 3)	(min.)	0	0	120	● ●
A8	Show warning if defrost is terminated by time-out 0=No, 1=Yes		0	0	1	● ●
A9	Alarm relay polarity 0=Relay ON in alarm (OFF no alarm) 1=Relay OFF on alarm (ON with no alarm)		0	0	1	● ●
A10	Temperature Alarm Differential (A1 and A2)	°C/F	0,1	1,0	20,0	● ●
A12	Door open alarm delay (if P10 or P11=1)	(min.)	0	2	120	● ●
EP	Exit to Level 1					● ●
Level 2 General status						
CnF	Level 3 Description	Values	Min.	Def.	Max.	
P0	Type of operation 0=Direct, Cold; 1=Inverted, Heat		0	*	1	● ●
P1	Delay of all functions on receiving electrical power	(min.)	0	0	255	● ●
P2	Access code (password) functions 0=Inactive; 1=Block access to parameters; 2=Keyboard lock		0	0	2	● ●
P4	Selection of type of input 1=1 probe + 2 digital inputs, 2=2 probes + 1 digital input		1	1	2	● ●
P5	Address (only systems with built-in communications)		0	1	255	● ●
P6	Configuration of AUX relay 0=Fan (only 2-relay equipment) 1=defrost 2=Alarm 3=Light		0	1	3	● ●
P7	Temperature display mode 0=Whole in °C 1=One decimal in °C 2=Whole in °F 3=One decimal in °F		0	1	3	● ●

AKO-D10323					
AKO-D10223					
AKO-D10123					
Level 1 Menus and description					
P8	Probe to be displayed (as per parameter P4) 0=visualization of all the probes in sequence; 1=Probe 1; 2=Probe 2; 3=Probe 3 (1)	1	1	2	● ●
P9	Selection of probe type 0=NTC; 1=PTC	0	0	1	● ●
P10	Configuring digital input 1 0=Off 1=Door contact 2=External alarm 3=Severe external alarm 4=Slave defrost 5=Act. ECO mode by pushbutton 6=Act. Fast Freezing 7=Not used 8=Remote defrost 9=Act. ECO mode by switch	0	0	9	● ●
P11	Configuring digital input 2 0=Off 1=Door contact 2=External alarm 3=Severe external alarm 4=Slave defrost 5=Act. ECO mode by pushbutton 6=Act. Fast Freezing 7=Not used 8=Remote defrost 9=Act. ECO mode by switch	0	0	9	● ●
P12	Digital input polarity 0= Energised on closed contact; 1= Energised on open contact	0	0	1	● ●
P13	Digital input polarity 0= Energised on closed contact; 1= Energised on open contact	0	0	1	● ●
P19	Lights in ECO Mode (P6=3)=ON; 1=OFF	0	0	1	● ●
EP	Exit to Level 1				● ●
tid	Level 2 Access and information control				
	Level 3 Description		Values	Min.	Def.
L5	Access code (Password)		0	-	99
PU	Program version (Information)		-	-	● ●
Pr	Program revision (Information)		-	-	● ●
EP	Exit to Level 1				● ●
EP	Exit Programming				



WARNING: The default parameters by type of application have been defined for the most common applications. Check that these parameters are suitable for your installation.

MESSAGES	
L5	Access code (Password) request
dEF	Indicates a defrost is underway. (Only if parameter d2=2)
E1	Probe 1 faulty (open circuit, crossover, NTC: temp. >99°C or <-50 °C PTC: temp. >150 °C or <50 °C) - (equivalent limits in °F)
E2	Probe 1 faulty (open circuit, crossover, NTC: temp. >99°C or <-50 °C PTC: temp. >150 °C or <50 °C) - (equivalent limits in °F)
AH	Flashing: maximum temperature alarm on probe 1 (A1)
AL	Flashing: minimum temperature alarm on probe 1 (A2)
AE	External alarm activated (only if parameter P10 or P11=2)
AES	Severe external alarm activated (only if parameter P10 or P11=3)
Adt	Defrost time-out alarm (only if parameter A8=1)
PAb	Door open alarm (Only if P10 or P11=1 and as per time at A12)

D: Displays the message on the display, **A:** Activates the alarm relay (if available).

7- Technical specifications

Power supply	AKO-D10123	230V~±10% 50/60 Hz 3.5VA
	AKO-D10223/D10323	230V~±10% 50/60 Hz 3.75VA
Maximum Voltage SELV circuits		20V
Inputs (According to P4)	AKO-D10123	1 input NTC/PTC
	AKO-D10223/D10323	2 inputs NTC/PTC + 1 digital input 1 inputs NTC/PTC + 2 digitals inputs
Relay COOL 16A		(EN60730-1:16(10)A 250V~)
Relay FAN 6 A		(EN60730-1:5(4)A 250V~)
Relay AUX 8 A		(EN60730-1:8(4)A 250V~)
Number of relay operations		EN60730-1:100,000 operations
Switches		16A 125Vac, 10A 250Vac T105 ¼ HP
Types of probe		NTC AKO-149xx / PTC AKO-1558xx
Measurement range NTC		-50,0 °C to +99,9 °C (-58,0 °F to 211 °F)
PTC		-50,0 °C to +150 °C (-58,0 °F to 302 °F)
Resolution		0,1 °C
Working environment		-10 a 50 °C, humidity <90 %
Ambient storage humidity		-30 a 70 °C, humidity <90 %
Class of protection - front panel		IP50
Fixation		Panel-mounted with anchors
Panel cutout dimensions		136 x 29 mm
Front panel dimensions		181 x 38 mm
Depth	AKO-D10123	43 mm
	AKO-D10223/D10323	61 mm
Connections		Screw terminals for cables up to 2.5 mm ²
Rating of control device: built-in, automatic operation feature Type 1.B, for use in clean environments, Class A software and continuous operation. Pollution classification 2 s/ UNE-EN 60730-1.		
Double insulation between supply, secondary circuit and relay output.		
Rated pulse voltage		2500V
Temperature during ball-pressure test	Accessible parts	75°C
	Parts which position active elements	125°C
Voltage and current as per EMC tests		207V, 17 mA
Current of radio jamming suppression tests		270 mA